



PO Box 16
State Hwy 173
Mather, WI 54641
800-657-4666
FAX 608-378-4199

INSTALLATION INSTRUCTIONS

The installation of Meadow Valley Log Siding requires a few simple tools; a tape measure, circular or miter saw, a chalk line, a square, and a hammer.

We recommend using galvanized splitless siding nails that will penetrate into the stud at least one and one quarter inches. The exception to this involves new construction. A contractor may choose to screw the siding onto the building from the inside of the home through the sheeting to hide the screws. For our larger siding profiles, like our full half log siding, a washer on the screw is recommended.

The siding should overhang onto the foundation by at least one inch. To determine the best coverage and the location of your first row, measure down from the eave to the foundation in inches. Divide the total number of inches by the wall coverage of the siding profile you are using to get the number of rows you will need. Round up for the number of rows.

Wall coverages: 2 x 6 – 4 5/8 inches 2 x 8 STD, MVP or RND – 6 ½ inches
2 ½ x 10 or full half log (4 ½ x 9) – 8 inches.

Based on the wall coverage and number of rows you will need, measure up on the wall and snap a level chalk line for the top of your first row. Fasten siding using galvanized splitless siding nails (some contractors prefer to use screws and sink the heads slightly) on the top side and the lower side of the log siding into each stud. (See nailing and fastening diagram)

Stagger the seams of your log siding, always butting the joints on a stud. The log siding should be fastened 16 inches on center. Continue working row by row upward until the last row, which may need to be cut lengthwise to fit.

For our Full Half Log Siding Profile (4 ½ inches thick) The recommended fastener is a 5/16 by 6 inch log screw. We also recommend using a long (10 or 12 inch) log screw every two to three feet to attach the log siding to the row beneath it. This is accomplished by screwing straight down through the siding so the screw “hits” the log piece below. When done correctly, no screws will be visible when attaching this siding, except on the top row. You may also fasten this profile from the inside of the home as suggested earlier.